

## 51/60-22 Installation Instructions

- Instantly converts your Cap & Ball to .22 Rimfire without any modification to the gun. Minor fitting may be needed due to gun manufacturer variations, please call Howell for further instructions.

### **Instructions:**

1. Place the hammer to the half-cocked position and remove the percussion cylinder.
2. Next, insert the .22 Rimfire Barrel liner into the breach of the revolver barrel. The steel bushing on the breach side of the liner has been secured with Loctite to prevent nut from turning.
3. Secure the liner with the hex bushing on the muzzle end. Lightly tighten with a 7/16" wrench. DO NOT OVERTIGHTEN.; damage to the threads may occur.
4. Insert the .22 conversion cylinder and slowly lower hammer onto a safety stop notch. Once cylinder is locked onto a safety stop notch, attach barrel. Note: Hammer should not be over a firing pin. There are 6 safety stop notches for ease of loading.